

How it's work?



How to apply a thermo patch

You need:

- Our thermo patch
- Iron
- A cotton cloth or paper towel

How to apply step by step:

1. Preheat the iron to the indicated temperature (160°C or 2 dots).
2. Place the patch sticky side down, exactly where you want it to be.
3. Cover the patch with a cloth or paper towel.
4. Place the iron on the fabric and press firmly for about 2 minutes.
5. Remove the cloth and check the attachment of the patch around the edges.

If you find parts that do not adhere to the edge, repeat the entire operation again.

And it's done! :)